

## VÝKRES S KÓTAMI - RÁM Z JEDNÉHO KUSU

Nižšie uvedené výkresy prehľadne znázorňujú dôležité rozmery pre správny výber dverok.  
 „X“ (šírka) x „Y“ (výška) stavebného otvoru

Rozmer	X	Y	A	B	C	D	E
150x150 mm RD	150	150	188	188	34		1
150x200 mm RD	150	200	188	238	34		1
150x250 mm RD	150	250	188	288	34		1
150x300 mm RD	150	300	188	338	34		1
200x200 mm RD	200	200	238	238	45		1
200x250 mm RD	200	250	238	288	45		1
200x300 mm RD	200	300	238	338	45		1
250x250 mm RD	250	250	288	288	45		1
250x300 mm RD	250	300	288	338	45		1
300x300 mm RD	300	300	338	338	45		1
300x400 mm RD	300	400	348	448	45		7
300x500 mm RD	300	500	348	548	45		7
300x600 mm RD	300	600	348	648	45		7
400x400 mm RD	400	400	448	448	45		7
400x500 mm RD	400	500	448	548	45		7
400x600 mm RD	400	600	448	648	45	155	7
500x500 mm RD	500	500	548	548	45	155	7
500x600 mm RD	500	600	548	648	45	155	7
600x600 mm RD	600	600	648	648	45	155	7
600x800 mm RD	600	800	668	868	45	155	7
800x800 mm RD	800	800	868	868	45	155	7

